


Highlights on advanced topics

Beginners' FLUKA Course

This is not the end ...

- As said in the first day, most applications can be run through data-cards only, exploiting the FLUKA built-in capacities
- Sometimes, more is needed...
- A set of templates User Routines is provided in the \$FLUPRO/usermvax directory
- All common and default parameters are located in **\$FLUPRO/flukpro**
- These can be modified by the user to fit his input/output needs
- We'll give here some hints of what can be done, more can be found in the manual, in the fluka-discuss archive, or

at the FLUKA workshop and advanced course to be held in TRIUMF Canada, autumn 2012



dN/dx

3

Implementing customized beam distributions - 2

Input card: SOURCE

User routine: **\$FLUPRO/usermvax/source.f** to be linked in one's own executable !

In source.f

you can sample beam particle position, direction, and energy from an external file or any (analytic or numerical) distribution

you can assign different weights to primary particles

you can load reaction products in the same primary history


several sampling routines already exist in the FLUKA code

parameters input in the SOURCE card are available


a BEAM card with a momentum/energy higher than the maximum one is still needed for initialization purposes (to define the tabulation limit)


Implementing magnetic field - 1


CERN Neutrino to Gran Sasso



The two magnetic lenses (blue in the sketch) align positive mesons towards the Decay tunnel, so that neutrinos from the decay are directed to GranSasso, 730~km away Negative mesons are deflected away The lenses have a finite energy/angle acceptance









Implementing customized scoring - 1

beam crossing in ATLAS



complete geometry - vertical crossing scheme



Implementing customized scoring - 2

Input card: USERDUMP

User routine: **\$FLUPRO/usermvax/mgdraw.f** to be linked in one's own executable !

In mgdraw.f

you can get particle trajectories and (continuous and local) energy losses

you can go over reaction products

you can access information at each boundary crossing, particle step, energy deposition event, *interaction*

In mdstck.f (for which no activating card is needed) as well, with the additional – dangerous – possibility of influencing the subsequent transport of secondaries

Implementing customized scoring-3

Input card: USERWEIG

User routines: \$FLUPRO/usermvax/<u>comscw.f</u> \$FLUPRO/usermvax/<u>fluscw.f</u>

to be linked in one's own executable !


In comscw.f

you can apply a user defined weight (even discard) on deposited energy, stars or residual nuclei

you can extract information (and dump it on a file) about the involved particles

In fluscw.f

same as comscw.f for fluence scoring.



you can keep track of the particle origin

stupre.f applies in case of electrons, photons and positrons

Implementing region independent importance biasing

Input card: **BIASING**

User routines: **\$FLUPRO/usermvax/usimbs.f** to be linked in one's own executable !

usimbs.f

This routine is called for every particle step in user defined regions where the user has to return the change in the importance from the beginning to the end of the step, in a region-independent way!

It doesn't produce as accurate results as the manual region biasing, but it is a great time saver for complex geometries where segmenting the existing geometry can be a more complex task

Particle properties altering per material/region

Input card: MAT-PROP

User routines: **\$FLUPRO/usermvax/usrmed.f** to be linked in one's own executable !

usrmed.f

Usage: Dynamic particle threshold for all kind of particles per region, material, lattice...; Alter the direction and position of a particle; Assign a call to the routine for selected materials with the use of MAT-PROP with sdum:USERDIRE

Define your own logic inside the routine